

ELECTRONIC TDS-TEST

1. Take off bottom black cover cap.
2. Switch the tester on.
3. **Only leave the bottom part uncovered by black cover cap to soak.**
Shake the **TDS-Test** slowly in the water.
- 4- Read value ; if the figures change, after 2 minutes they will stabilise.
The indicated value is for a temperature of 20°C.
For a different temperature, the **TDS-Test** needs some instants to compensate the temperature difference.
- 5- Switch the tester off and put away the device.

Limits of the device : 0 to 1990 ppm

Technical information given without any contractual warranty.

Mareva – The Happy Pool